

Traditional Machines

Daily Cleaning Guide

You Will need:

- Protective gloves
- Group Head Cleaning Brush
- Rubber Cleaning Disc
- Cimballi Ecocleaner
- Suitable Soaking Container (1 Litre)

HEALTH AND SAFETY ADVICE

- Always use protective gloves when handling chemicals
- Always hold the steam wand by the rubber grip
- CAUTION - The steam wand may spray some water out when first used, or after a period of not being used
- Filter Baskets maybe VERY HOT when being removed to clean
- Do not put group handles in a dishwasher

1



Remove group handles from each coffee head.

7



Repeat steps 1 - 6 for each head.


2




Run the cleaning brush around the seal to remove any coffee grounds.

8



 Make up a solution of 2 teaspoons of Cimballi Ecocleaner with 1 litre of hot water.

3



Use the centre (stop) button to run water for a few seconds.

9



Remove the baskets from the group handles and the nozzle from the Turbosteam. Soak in the solution overnight, remove, rinse with clean water and wipe clean.

4



Place the rubber-cleaning disc into the group handle. Add 1/2 teaspoon of Cimballi Ecocleaner.

10



Place filter baskets back in the group handles, reinsert all handles into the groups and rinse thoroughly.

5



Reinsert the group handle into the group.

11



Remove and clean drip tray with a damp cloth.

6



Press the centre (stop) button to start the group and count to 5. Then press the centre (stop) button again to stop it. Repeat step 6 (5 times)

& remove the handle and rinse. Re-insert the handle and repeat step 6 to rinse the head thoroughly.



Caution: do not remove group handle whilst machine is running.

12



Remember:

- Always purge the steam wand before and after use.
- Always wipe the steam wands after use.
- Never soak the steam wands!

- Service Line Number: 020 8238 7101
- To re-order cleaning materials Fax Number: 024 7671 2799

LA **CIMBALI**